

Instructions



VIDEO INSTRUCTIONS


Scan the QR code or go to feactive.com/instructions

#THEJOURNEYFORWARD

JOIN OUR COMMUNITY

of **adventurers** and
outdoor enthusiasts

Discover new places and stories. Share your unique experiences. Ask questions. Give advice. Enjoy the beauty this world has to offer and live it alongside fellow adventurers and outdoor enthusiasts. Welcome to the **FE Active** family, we hope you'll feel like home in our online community.


 [feactive](#)  [FE Active](#)

 [FE Active](#)  [feactive.com](#)

 [FE Active](#)  [feactive.com](#)




1




Securely attach all poles to the corresponding holes. Use the internal bungee cords and plastic inserts to bind the frame and legs together.

2




Carefully attach the 4 corners of the fabric to the corresponding poles that are pointing upwards.

3



The rocker's chair legs come in two pieces. Slide the pieces into place and push the pins until they lock.

4



Align the four outer ridges on the rockers with the chair legs. Push them together until they snap into place.

 **250lbs**
113kg

THE LOYALTY PROGRAM

Hop over to our website and become a member - it's free! Earn points through orders and social media and then **exchange** the points for **rad gear**!